

BARE

CONCRETE

CONCRETE WAX APPLICATION

Using a slightly damp applicator, wipe Bare Concrete Wax onto the surface, applying in a circular hand motion that allows for 20-25% overlap and no missed spots. Leave for a few minutes and buff with a felt or lambswool buffing wheel. Apply once a year or when required.

